

## Key Switch Control

The MxPro 5 control panel range supports direct installation of up to 8 individual key switches.

### Applications

The MxPro 5 1 loop permits 1 key-switch to be fitted, but the MxPro 5 2 & 4 loop control panels allow a maximum of 8.

### Features

- Enable/disable controls
- Group isolate to disable I/O across network
- For use to start/enable a class change
- Trapped and un-trapped key switches available
- Control of multi-sensor/device sensitivity mode change
- Simple to install and configure
- Trapped and Un-trapped key switches

### Order Codes and Options

Mxp-511(F):	Access Enable Key Switch
Mxp-515(F):	3-position Key Switch - Trapped (requires 2 inputs)
Mxp-516(F):	2 Position Key Switch Assembly - Trapped
Mxp-517(F):	2 Position Key Switch Assembly - Un-Trapped
Mxp-518(F):	Access enable key switch for Mx-5010/5020/5030
Mxp-519(F):	2 Position key switch - Momentary contact
Mxs-511:	Spare access enable Key Switch (Lorlin style)
Mxs-516:	Spare 2 position Key Switch - Trapped (Lorlin style)
Mxs-517:	Spare 2 position Key Switch - Un-Trapped (Lorlin style)

### Compatibility

Can be used with all MxPro 5 series control panels.

### Limitations

If an on-board printer is fitted to the MxPro 5 2 & 4 loop control panels then the maximum number of switches fitted is limited to 4. If the MxPro 5 3 position switch is fitted, then two programmable inputs must be available per switch.

[Check if this document is up to date](#) | [Give us feedback](#)

Advanced, The Bridges, Balliol Business Park, Newcastle, NE12 8EW, UK T: +44 (0)845 894 7000, E: [enquiries@advancedco.com](mailto:enquiries@advancedco.com), W: [www.advancedco.com](http://www.advancedco.com)

As our policy is one of constant product improvement the right is therefore reserved to modify product specifications without prior notice.